


**FULLMOTION COMPRESSORS
ELECTRONIC INVERTER**

Product Manual
Fullmotion CF10C



BEFORE YOU BEGIN



Incorrect operation could result in bodily injury or death due to electrical hazard.



Incorrect operation could cause bodily injury or could result in equipment damage.

NOTICE

Contain helpful suggestions or references to material not covered in this document.

Contents

1	INTRODUCTION	1
1.1	Product description	2
1.1.1	Stand alone inverter	2
1.1.2	Institute approval	2
1.2	VNE compressor series description	3
1.3	FMF and VEG compressor series description	4
1.4	Product handling	4
1.5	Dimensions (mm)	5
1.5.1	FMF and VEG compressor series	5
1.5.2	VNE compressor series	6
1.6	Package information	6
2	TECHNICAL SPECIFICATIONS	8
2.1	Nomenclature	8
2.1.1	Label information	9
2.2	Product specifications	9
2.3	Inverter enclosure	11
2.3.1	Product dimensions	11
2.3.2	Connectors	11
2.3.3	Product discards	14
2.4	Information about input inrush current	15
3	INSTALLATION	16
3.1	Assembly instructions	16
3.1.1	VEG and FMF compressor cable connection	17
3.1.2	VNE compressor cable connection	19
3.1.3	Forced ventilation	22
3.1.4	Optional AC Fan switch control	24
3.1.5	Inverter cables arrangement	25
3.1.6	Input cable with ferrite filter	27
3.2	Electrical Installation	28
4	OPERATION	29
4.1	Frequency control mode	29
4.2	Drop-In control mode	31
4.2.1	First time Pull-down	32
4.2.2	Normal cycling	32
4.2.3	Connection	32

CONTENTS

4.3	Serial control mode	33
4.3.1	Serial specifications and Internal Circuit	33
4.3.2	Commands	35
5	DIAGNOSTICS	39
5.1	LED indication	39
5.2	Troubleshooting	40

GENERAL PRECAUTIONS



- During installation the environment must be properly protected against ESD. The operator and machines must be properly Earthed.
- Make sure that Fullmotion CF10C Inverter will not be in direct contact with flames during assembly.
- The location where the Inverter will be installed must be protected against splashed water from all directions.
- Do not open the Inverter enclosure. For installation, remove only the Inverter Cover to make the electrical connections.



- This inverter is for use only with the Fullmotion Embraco compressors.
- Read this material carefully before you begin the Fullmotion CF10C Inverter installation and start up procedure.
- To prevent damage to your inverter during and after assembly, avoid contacting with the following substances: Hydrocarbons; Ester based oils (e.g.: compressor oil); Phenols; Amines; Ketenes; Automotive fluids such as grease, except glycol and heavy alcohol.

NOTICE

- The protection against access to live parts have been evaluated according to the relevant requirements from IEC 60335-1 and UL 60730-1.

Chapter 1

INTRODUCTION

Embraco's Fullmotion compressors are ideal for commercial applications where wide voltage range, fast pull down, better performance, fine temperature control, lower power consumption and very low noise and vibration levels are required. This is possible thanks to the use of an electronic inverter capable of driving the compressor at different speeds and consequently, controlling its refrigeration capacity.

Efficiency


Fullmotion Compressors technology allows the compressor to operate at different speeds, adjusting it according to demand. When side by side with a conventional compressor, the energy consumption is up to 45%.

Flexible

Indicated for commercial refrigeration system, provides more flexibility in customized solutions through inclusion of electronics already coupled to the compressor, opening a wide variety of applications.

1.1 Product description

1.1.1 Stand alone inverter



Composed by

Indicator	Description
1	Plastic body
2	Plastic cover
3	Compressor cable output connection
4	Input/ Earth/ Communication cables connection

Figure 1.1: Stand alone view

NOTICE

CF10C inverter series are designed to be used only in built in appliances, with not accessible machine compartment.

1.1.2 Institute approval

Institute approval


CF10C Inverter



Approved according to
EN 60335-1

1.2 VNE compressor series description

- 1- Fence cover
- 2- OLP
- 3- 3/4 OLP
- 4- Cord anchorage
- 5- Screw
- 6- Grommets
- 7- Compressor shell
- 8- Process tube
- 9- Discharge tube
- 10- Suction tube




CAUTION

- Before you begin your installation observe technical specifications and proper connections.
- Check if product is properly identified and if it's enclosure is without cracks.

1.3 FMF and VEG compressor series description

- 1 - Fence cover
- 2 - Cord anchorage
- 3 - Screw
- 4 - Grommets
- 5 - Compressor shell
- 6 - Process tube
- 7 - Discharge tube
- 8 - Suction tube



1.4 Product handling




CAUTION


- Inverter is sensitive to Electrostatic Discharges. Take care with product handling until final assembly.
- Special care must be taken to avoid mechanical impacts on the inverter during assembly process.
- The environment must be properly protected against ESD.
- The workers that handle the inverter must be Earthed through adequate ESD wrist strap and must wear ESD gloves.
- Do not hold by the wiring.
- Do not use the inverter if it drops during handling.

1.5 Dimensions (mm)

1.5.1 FMF and VEG compressor series




1.5.2 VNE compressor series



1.6 Package information

The inverters are packed in a carton box. Figure 1.2 shows the used box to pack the product. The quantity of products inside the box may change due to internal or external requirements. Box dimensions can be changed without previous information.



*Dimensions are in mm.

Figure 1.2: Product package

Chapter 2

TECHNICAL SPECIFICATIONS

2.1 Nomenclature

CF 10 C KK X U.Y VV W ZZ

CF	Driver Type
10	Family
C	Generation
KK	Subversion
X	Power Supply
U.Y	Protective Function
VV	Electronic Configuration
W	Enclosure
ZZ	Cables and Peripherals

Example: CF 10 C02 N 0.1 01 A 00

CF	Fullmotion controller
10	High power series (500 W - 1000 W)
C	3 rd generation
02	Product subversion
N	Single Voltage 50 - 60 Hz
0.1	HW PEC version 1
01	Electronic configuration version 01
A	Stand Alone
00	Cable configuration version 00

**WARNING**

- Do not connect the Fullmotion CF10C Inverter to a power supply above 264 V.

**CAUTION**

- For operation below the rated voltage, the maximum compressor cooling capacity can be reduced as consequence of speed limitation.
- Confirm compressor type and speed rotation at compressor datasheet.
- In order to avoid loss of performance, make sure to operate the inverter inside the temperature range of -20 °C to 50 °C.
- Ambient operation temperature above 50 °C may activate inverter thermal protection.

NOTICE

- Voltage range relates to product robustness, not institute approval.
- Maximum power is not reached under all input voltage range.
- Output frequency and motor speed may have reduced range based on maximum working conditions of the respective compressor.

*VDE agency approval temperature.

†Air flow over the inverter heat sink, as shown in Figure 3.9.

‡Ingress Protection grades are described in IEC 60529 (Degrees of protection provided by enclosures).

2.3 Inverter enclosure

2.3.1 Product dimensions




Figure 2.1: Stand alone dimensions

Stand alone dimensions

Dimensions 170,2 mm x 199,5 mm x 119,5 mm

2.3.2 Connectors

This section presents the available connectors of Fullmotion CF10C Inverter, as well as their proper connections. The final enclosure without plastic cover is presented

to improve understanding. The manufacturer part number of each connector can be found in the following table.




Figure 2.2: Connectors

Connectors part numbers

Indicator	Description	Part number	Insulation
1	Serial Communication	S3P-VH (LF) (SN)	Reinforced
2	Frequency input	S2P-VH (LF) (SN)	Reinforced
3	Drop in	1217754-1	Functional
4	AC input (L+N)	1217754-1	Functional
5	AC Fan*	MSLO 9402 - 002 - 00A - 960 - 000 - 00	-
6	Additional Drop in (optional)	1217754-1	Functional
7	Safety Earth	63849-1	Basic

*Mates with 1/4" faston receptacle. Fan connector assemble is optional.




Figure 2.3: Motor cable for VEG and FMF compressor series




Figure 2.4: Motor cable for VNE compressor series with OLP




Figure 2.5: EMI Earth and Safety Earth Cable

Cable Specification			
Indicator	Description	Part Specification	Color
Figure 2.3	Standard Motor Cable	UL STYLE 2586 105°C 600 V	Black, Blue and Brown
Figure 2.4	Motor Cable With OLP	UL STYLE 2586 105°C 600 V	Black, Blue and Brown
Figure 2.5	Safety Earth Cable	UL STYLE 1015 105°C 600 V	Green/Yellow
Figure 2.5	EMI Earth Cable	UL STYLE 1015 105°C 600 V	White

Inside the inverter enclosure, the compressor motor and Earth cables must be connected as shown in Figure 2.6. Earth cables shall always be connected first to avoid ESD.




Figure 2.6: Motor cable

2.3.3 Product discards



CAUTION

- Do not remove the inverter from its case.
- Do not incinerate any Embraco's inverter. Contact your local authorities, if you need to incinerate this product for disposal.
- Inverters should not be mixed with general waste.

NOTICE

- If you wish to discard this product, please contact your local authorities or dealer for the correct method of disposal, for proper treatment, recovery and recycling.
- This device is RoHS compliant, nevertheless the correct disposal of this product will help to save valuable resources and prevent any potential negative effects on human health and the environment (e.g.: to avoid ground disperse) which could otherwise arise from inappropriate handling.

2.4 Information about input inrush current

Inrush Specifications

Allowed inrush events	1 per day
Inrush current (cold state)	235 A peak
Inrush current (hot state)	357 A peak
Input fuse melting (i^2t)	209 A ² s

Inrush current refers to a transient phenomenon that occurs rarely and only when the power supply cord is connected to the power grid or in the case of power grid shutdown. CF10C inverter series are designed accordingly and can reliably withstand this current along the expected product lifespan. Excessive inrush current events may damage the inverter. Regarding inverter installation, Embraco recommends to have the appliance supply cord directly connected to inverter power input without any disconnection means. Please, contact Embraco Technical Support for any assistance or application assessment needed.

Chapter 3

INSTALLATION

3.1 Assembly instructions




Figure 3.1: Inverter overview

The Fullmotion CF10C Inverter has a quick and easy assembly method. To perform the assembly steps, remove the plastic cover and make sure to correctly follow the instructions.

The Fullmotion CF10C Inverter comprises three basic elements:

1. Plastic body;
2. Electronic board;
3. Plastic cover;
4. Heat sink.

CF10C inverter is compatible with three compressor's family. Subsection 3.1.1 describes the compressor cable connection for VEG and FMF series, while subsection 3.1.2 the cable connection for VNE compressor series.

3.1.1 VEG and FMF compressor cable connection

To connect the inverter to the compressor, attach the motor cable on the hermetic compressor terminal, as shown in Figure 3.2 and Figure 3.3*.




Figure 3.2: Step 1




Figure 3.3: Step 2

After performing the connections, assemble the compressor fence cover as shown in the following sequence (Step 3 and 4).




Figure 3.4: Step 3




Figure 3.5: Step 4

*The figures displayed here are merely illustrative

NOTICE

Maximum force to connect the motor cable in hermetic terminal is 13.76 Kgf. To fix the inverter in the system the customer shall use a screw or washer with following specification: screw head or washer with minimum diameter of 10 mm; torque range from 1.5 to 2.0 Nm.

To disassemble the fence cover, the following sequence must be adopted*.

1. Introduce a screwdriver into the clip in the top of the fence cover and push it down;
2. To remove the cover, push it down and pull out of the compressor.




Figure 3.6: Step 1





Figure 3.7: Step 2


*The figures displayed here are merely illustrative

3.1.2 VNE compressor cable connection


To connect the inverter to the compressor, attach the motor cable on the hermetic compressor terminal, as shown in the sequence*.




Step 1:
Check the cord anchorage position on the fence support (1).



Step 2:
Slide cord anchorage snap for attachment on fence (2).




Step 3:
Grounding terminal to fasten the screw in cord anchorage bracket (3) (screw torque 0.1 - 0.6 N.m.).



Step 4:
Insert OLP bracket in the hermetic terminal pin (4).


*The figures displayed here are merely illustrative

**Step 5:**

Inverter conector insertion in the compressor hermetic terminal (5).

Step 6:

Insertion of grounding cable

**Step 7:**

Inverter terminal cables on OLP (7).

Step 8:

Inverter cables positioning on cord anchorage bracket (8).



Step 9:

Insert and screw the cable clip (screw torque 0.7 - 1.2 N.m.).


Step 10:

Complete electrical cables fastening.


Step 11:
Place terminal board cover on fence support top-down (11) until complete fit (12).



To disassemble the fence cover, the following sequence must be adopted



Step 1:
Using a screw driver, push the keys in tabs of terminal board cap.



Step 2:
Force the tabs on the opposite direction (13) and then move the cap up (14).



- Before obtain access to connectors, disconnect the AC power supply.
- Avoid contact of the Control Input Cable (low voltage) with high voltage or power supply cables, due to electrical hazard and potential equipment damage.

NOTICE

- Please, before employing the inverter with compressor, refer to compressor technical documentation not covered in the manual. In case of doubt, please, contact Embraco technical support.



- Motor connector must be properly mounted on the 3 pins of compressor hermetic terminal. Bad connection will cause compressor malfunction.
- The screws shown in Figure 3.1 and Figure 3.5 must be fixed with a torque within 0.8 – 1.2 Nm range.
- The handling of Inverter enclosure must be careful to avoid contact with the internal electronic board, in order to prevent possible electrostatic discharges.
- Make sure all necessary connections are properly done before connecting the Inverter to AC supply line.
- The electronic Inverter must be installed in the vertical position.
- When using Serial or Frequency communication mode the inverter has reinforced isolation. When using Drop-in mode (energized contact) the inverter has functional insulation.
- In order to avoid ESD discharge to the inverter circuit, insert the earth terminals at first.

3.1.3 Forced ventilation

Recommended position of fan + compressor + inverter are shown in the figure 3.8.*.

All mentioned positions are acceptable. Considering specific aspects as inverter and motor-compressor cooling, the most recommended are positions 1-4. The last recommended but still acceptable are positions 5 and 6.

Both air flow directions are acceptable, but position above illustrated is preferred. The inverter heat sink air flow is shown in Figure 3.9. As reference, the heat sink also is shown on Figure 3.1.

*The figures displayed here are merely illustrative




Figure 3.8: Air flow direction




Figure 3.9: Inverter air flow direction



- In order to avoid loss of performance, make sure that the heat sink is not obstructed from the air ventilation.
- Maximum power is only achieved with minimum forced ventilation of 2 m/s over the inverter heat sink and 520 m³/h air flow over the compressor.
- Fan to compressor shell distance must be less than 30 cm.

3.1.4 Optional AC Fan switch control

CF10C inverter series can be equipped with AC Fan switch control. This switch is ON in case compressor is running and OFF once compressor is stopped. Note, that AC Fan switch control is not powered. It operates like a switch to interrupt the AC supply Line or Neutral of the FAN.

Following connections to be made for switching power of the AC Fan:

- one terminal of AC Fan output to the Phase (or Neutral);
- second terminal of AC Fan output to customer's AC Fan terminal;

- the remaining terminal of customer's AC Fan to the Neutral (or Phase).

3.1.5 Inverter cables arrangement

The input and communication cables are not provided by Embraco. Therefore, inverter cables must be arranged according to the following instructions.

1. Push/pull repeatedly the cover plastic flap until it detach as much as necessary to pass the cables.
2. Take care to positioning the EMI earth (when applied) and Safety earth cables with the protecting tape beneath the cord relief as shown in Figure 3.10.
3. The cables must pass through the cord relief as shown in Figure 3.11.
4. Assemble the cord relief.




Figure 3.10: Cables arrangement

Routing Description

Indicator	Description
1	AC Input Cable
2	EMI Earth Cable (optional)
3	Communication Cable
4	FAN Cable
5	Cord Relief
6	Fixing Screw




Figure 3.11: Cord relief assembly

The compressor motor cable assembly is through the inverter enclosure and must follow the sequence shown in Figure 3.12.

Motor Cable Routing Description

Indicator	Description
1	Compressor Cable
2	Cord Relief
3	Fixing Screw




Figure 3.12: Compressor cable cord relief



- On the mains terminal (L or N) use insulated female FASTON terminals in order to prevent any risk of short-circuit due to terminals bending.
- Avoid routing cables over the cord relief, otherwise the product may damage due to mechanical stress.
- The screw shown in Figure 3.11 must be fixed with a torque within 0.8 - 1.2 Nm.
- After concluded the routing, the plastic cover must be reassembled, fixing the screw with a torque between 0.8 - 1.2 Nm.

NOTICE

The approval of the input supply cables specifications and certifications as well as the cord relief interaction with the input cables is customer responsibility.

3.1.6 Input cable with ferrite filter

CF10C inverter may be supplied with an input cable with ferrite filter. The Figure 3.13 shows the input cable with ferrite filter aspect.




Figure 3.13: Input cable with ferrite filter

3.2 Electrical Installation

In single-phase installations, the line phase wire must be protected by a circuit breaker. Furthermore, the line phase wire must be connected to the phase input connector of the inverter and the line neutral to the neutral input connector of the inverter.




Figure 3.14: Phase-Neutral connection

In the case of two-phase installations, it is mandatory to use a 2-pole circuit breaker, because in case of a short circuit both phases of power supply are protected.




Figure 3.15: Phase-Phase connection

Chapter 4

OPERATION

The Fullmotion CF10C Inverter have support for Serial, Frequency and Drop-In communication modes.




CAUTION


- The inverter is assembled with all communication modes and the control mode is chosen automatically by the inverter.

4.1 Frequency control mode

In this operation mode the compressor speed is controlled through a frequency signal sent to the inverter. Usually this signal is provided by an electronic thermostat. The frequency signal is a digital square wave and its characteristics are described on Signal specification table and Figure below.




0.7 V to 4.5 V the inverter behaviour is indefinite, therefore, it is not recommended to use signals within this range. The following figure presents a graphic example of an input frequency signal of 125 Hz sent to the inverter. The digital signal duty-cycle can vary in the range from 30% to 70%.



The compressor will follow frequency signal sent to the inverter according to the relation described on the following table and illustrated on the graph below.

Input Frequency Signal [Hz]	VNE compressor speed [RPM]	VEG and FMF compressor speed [RPM]
0 to 50	0	0
50 to 60	2000	1800
60 to 66	2000	30 x Hz
66 to 150	30 x Hz	30 x Hz
>150	4500	4500



The Figure 4.1 shows the electrical connections to perform frequency communication between an electronic thermostat and Fullmotion CF10C Inverter Control connector. For Frequency Control Mode, the input resistance is 1.2 kΩ.




Figure 4.1: Electrical schematic of frequency communication

The following figure shows the right way to perform the Frequency Control Mode connection according to the connectors described in Figure 2.2.




Figure 4.2: Frequency control mode connection

4.2 Drop-In control mode

The Drop-In mode is a Fullmotion CF10C Inverter control mode, where single thermostat contact is used to set the compressor running conditions. Drop-In mode allows the application to any refrigeration system with a simple ON/OFF thermostat, without needing a control signal coming from an electronic thermostat. The compressor speed will be adjusted automatically by the Inverter, in accordance to the thermal load variation.


4.2.1 First time Pull-down

After 3 minutes of intermediary speed, the speed is increased to maximum and it is kept at this rotation until the thermostat opens, switching the compressor off.

4.2.2 Normal cycling

Compressor speed increases and decreases proportional to thermal load variation during compressor running time. Optimum speed will be targeted to minimize energy consumption. If thermal load remains constant for a period longer than 20 minutes, the compressor speed is increased.

Compressor speed versus thermostat behavior



4.2.3 Connection

The Drop-In mode connection shall be wired according to Figure 4.3. The connection is an Energized Contact and must be used when the thermostat control signal is energized directly from the AC phase. This signal is usually called Thermostat Return Signal.




Figure 4.3: Energized Contact Drop-In connection



- When opened, the thermostat impedance must be higher than 380 k Ω . Otherwise the compressor can run continuously, without ever turning off.

NOTICE

- All main parameters, such as minimum and maximum speed are described at compressor datasheet.

4.3 Serial control mode

This option is used when an electronic thermostat controls the CF10C Inverter uses a serial communication protocol. Based on Embraco protocol it is possible to define the compressor speed and check other parameters.

4.3.1 Serial specifications and Internal Circuit

The Serial Control mode has an isolated input stage provided by the usage of optocouplers. The circuit on Figure 4.4 shows the electrical connections to perform serial communication between an electronic thermostat and Fullmotion CF10C Inverter serial connector (CN204).

The input resistance for serial communication, shown in Figure 4.4, is 1.2 k Ω .






Figure 4.4: Electrical schematic of serial communication

To guarantee the correct functionality of serial communication, the signal to be sent to the inverter must be according to the following values.



Example: 39h sent to inverter



The identification byte (1st byte), is used for command synchronization. After inverter identifies a valid A5h, it starts to read the next 4 bytes. After reading, a re-

sponse will be sent as indicated on "Receive commands structure" table. No response will be sent until the inverter recognizes a byte A5h. There is a time out of 2 seconds to receive the entire command after inverter identifies one A5h. After this time out, a new synchronization will start.

Basic specification

Communication type	UART (Half-Duplex)
Baud rate	600 baud
Parity	None
Flow control	None
Unit size	5 Bytes
Electronic thermostat	Host
Inverter	Slave

To perform serial communication between a computer (RS-232) and the Fullmotion CF10C Inverter serial connection, please contact Embraco Technical Support to receive instructions.

4.3.2 Commands

Command structure

1st Byte	2nd Byte	3rd Byte	4th Byte	5th Byte
Identification (ID)	Command (CMD)	LSB*	MSB**	Check-sum*** (CK)

*Least significant Byte (LSB) of Data. Example: Data=ABCDh, thus Data low=CDh.

**Most significant Byte (MSB) of Data. Example: Data=ABCDh, thus Data high=ABh.

***Checksum=100h - (S14h AND 0FFh), where S14h is the addition of Bytes 1 to 4.

Transmit commands structure

Command	ID	CMD	LSB	MSB	CK
Set speed	A5h	C3h	Speed [RPM]		CK
Read set speed	A5h	3Ch	80h	39h	CK
Read operation status	A5h	3Ch	83h	39h	CK
Read power	A5h	3Ch	82h	39h	CK
Read starting trials	A5h	3Ch	81h	39h	CK
Read bus voltage	A5h	3Ch	84h	39h	CK
Read temperature	A5h	3Ch	88h	39h	CK
Read power limitation	A5h	3Ch	8Ah	39h	CK
Serial set speed overwrite	A5h	69h	[Note]	93h	CK

Receive commands structure

Response to:	ID	CMD	LSB	MSB	CK
Set speed	5Ah	83h		Status*	CK
Read set speed	5Ah	80h		Speed [RPM]	CK
Read operation status	5Ah	83h		Status*	CK
Read power	5Ah	82h		Power [W]	CK
Read starting trials	5Ah	81h		Number of trials	CK
Read bus voltage	5Ah	84h		Voltage [V]	CK
Read temperature	5Ah	88h		Temperature [°C x 10]	CK
Read power limitation	5Ah	8Ah		Power limitation [W]	CK
Serial set speed overwrite	A5h	C3h	[Note]	00h	CK
Communication error	5Ah	Code**	FFh	FFh	CK

*See Status Data table.

**See Error Code table

[Note]: Serial set speed overwrite status/command:

00h – Serial set speed does not overwrite the thermostat set point

01h – Serial set speed overwrites the thermostat set point

Remark: if there is no serial communication for more than 4 h then the overwrite command is resetted.

Status Data

H Bit	LSB	MSB	Description
-	-	00h	Compressor running
-	-	FFh	Compressor stopped (waiting for a valid start speed)
0	01h	FFh	Start failure
1	02h	-	Overload protection (Note 1)
1	02h	FFh	Overload (Note 3)
2	04h	FFh	Under speed (1550 rpm or lower)
3	08h	FFh	Wrong rotor position
4	10h	FFh	Short circuit
5	20h	FFh	Over temperature failure (Note 6)
7	80h	-	Set speed data out of specification (Note 2)
7	80h	FFh	Set speed data out of specification (Note 4)

Note 1 : This response occurs when compressor is running with a high load. If the Data High byte is 00h, compressor is still running.

Note 2 : Response to the out-of-spec set speed data received while the comp is running.

Note 3 : This response occurs when compressor is stopped due to high load.

Note 4 : Response to the out-of-spec set speed data received while the comp is

stopped.

Note 5 : When one or more errors occur, the corresponding bits "H" are set to 1.

Example: Overload and Under speed: 0xFF06

Note 6 : The over temperature failure refers to when the inverter turns off due to the temperature overcoming 105°C, not to the temperature protection actuating.

Error Code

Code	Error
F0h	Error in 4th Byte
F2h	Checksum error
F4h	Command error
F8h	Error in the 3rd Byte

If compressor is stopped due to a failure (see Data Status table), it is possible to reset that failure sending a speed command to turn inverter off (0 rpm set speed). However, if nothing is done, the failure reset will occur after 8 minutes and then the compressor will try to restart. The following example shows a situation where the compressor speed is set at 2000 RPM.

Example: Set compressor at 2000 RPM

Step 1: select proper command

Command for selecting a speed is **Set speed**

ID →A5h

CMD →C3h

Step 2: transform speed from decimal into hexadecimal base

2000d →07D0h

Step 3: split lower and higher Bytes

LSB →D0h

MSB →07h

Step 4: calculate sum of first 4 Bytes

S14h=A5h+C3h+D0h+07h

S14h→23Fh

Step 5: boolean logic to maintain sum as 8-bit

L14h=0FFh AND S14h

L14h →3Fh

Step 6: calculate checksum

CK=100h-(0FFh AND S14h)=100h-3Fh

CK= →C1h

Command: A5h C3h D0h 07h C1h

NOTICE

- To avoid noise increasing and damages to the compressor due to mechanical resonance, some operating speeds are forbidden by software for all control modes.
- When one or more errors occur, the corresponding "H" bits are set to 1. Example: Overload and Under speed **LSB** →**06h**.
- The Frequency and Drop-In modes can have serial communication only for monitoring purpose. This functionality can be used for product diagnostic.

Chapter 5

DIAGNOSTICS

The Fullmotion CF10C Inverter has two diagnostics methods, by visual light emission using a LED indication, or by serial communication protocol.

5.1 LED indication

The LED diagnostics function helps services technicians to diagnose possible fault components by blinking a LED inside the box in different patterns. Basically, it indicates if there is a problem with Compressor, CF10C Inverter or Thermostat. The table below describes the failure modes.

LED Status	Period	Color	Description
1 Flash	30 seconds	Green	Normal operation
2 Flashes	5 seconds	Green	Communication problem
3 Flashes	5 seconds	Red	Inverter problem
4 Flashes	5 seconds	Orange	Compressor problem
No Flash	-	-	No input power / Damaged inverter

5.2 Troubleshooting

The following tables shows some possible problems and the best action to deal with them.

Compressor does not start

Problem	Action
Compressor disconnected from the inverter.	·Verify compressor cable connection.
No AC power supply; or wrong voltage/terminals connected.	·Verify AC input cable connection and measure AC input voltage.
No control signal input or bad connection.	·Verify control input cable connection and measure the signal from the thermostat.
Blown fuse (due to previous major failure).	·Return the unit to manufacturer, replacing it by new one.
Open compressor motor winding.	·Measure winding for open circuit between all pair of pins on the hermetic terminal. If any winding is open, return compressor to manufacturer.
Compressor with locked rotor (due to mechanical damage).	·Replace compressor by new one and test for confirmation. Return damaged unit to manufacturer.
Dropped, damaged, burnt inverter.	·Replace by new one and test for confirmation. Return damaged unit to manufacturer.
Inverter on waiting time after failed start.	·Wait the necessary time or reset the inverter disconnecting it from the AC power supply. The reset time is about 50s.
Demagnetized rotor (only if compressor was previously connected directly to the AC power supply).	·Replace compressor by a new one and test for confirmation. Return damaged unit to manufacturer.
Unequaled pressures between discharge and suction pressures in the refrigerating system.	·Allow the Inverter to equalize pressure between suction and discharge sides.
Low input voltage supplied to the inverter.	·Measure AC voltage to confirm.

Compressor does not run at the selected speed


Problem	Action
High compression load, with compressor being subjected to a stall condition.	·Review system design,refrigerant gas load or compressor capacity is not suitable for the application. If system is apropiated designed, speed will reach set value when load condition is stabilized.
Compressor always on pulldown cycle for Drop-In Mode.	·In Drop-In mode, check if the inverter AC input is connected to thermostat output. Inverter AC input should be directly connected to AC power supply (see Drop-In mode schematic).
No or incorrect control signal.	·Check if the appropriate control signal is being correctly applied to the Control Input Connection.

DISCLAIMER

The Fullmotion CF10C Inverter is for use only with the Embraco compressors. ALL PRODUCT, PRODUCT SPECIFICATIONS AND DATA ARE SUBJECT TO CHANGE WITHOUT NOTICE TO IMPROVE RELIABILITY, FUNCTION OR DESIGN OR OTHERWISE.

Embraco, its affiliates, agents, and employees, and all persons acting on its or their behalf (collectively, "Embraco"), disclaim any and all liability for any errors, inaccuracies or incompleteness contained in any datasheet or in any other disclosure relating to any product. Embraco makes no warranty, representation or guarantee regarding the suitability of the products for any particular purpose or the continuing production of any product. To the maximum extent permitted by applicable law, Embraco disclaims (i) any and all liability arising out of the application or use of any product, (ii) any and all liability, including without limitation special, consequential or incidental damages, and (iii) any and all implied warranties, including warranties of fitness for particular purpose, non-infringement and merchantability.

Statements regarding the suitability of products for certain types of applications are based on Embraco's knowledge of typical requirements that are often placed on Embraco products in generic applications. Such statements are not binding statements about the suitability of products for a particular application. It is the customer's responsibility to validate that a particular product with the properties described in the product specification is suitable for use in a particular application. Parameters provided in datasheets and/or specifications may vary in different applications and performance may vary over time. All operating parameters, including typical parameters, must be validated for each customer application by the customer's technical experts. Product specifications do not expand or otherwise modify Embraco's terms and conditions of purchase, including but not limited to the warranty expressed therein. Except as expressly indicated in writing, Embraco products are not designed for use in medical, life-saving, or life-sustaining applications or for any other application in which the failure of the Embraco product could result in personal injury or death. Customers using or selling Embraco products not expressly indicated for use in such applications do so at their own risk. Please contact authorized Embraco personnel to obtain written terms and conditions regarding products designed for such applications. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document or by any conduct of Embraco. Product names and markings noted herein may be trademarks of their respective owners. All trademarks in this material are property of the respective companies. EMBRACO is trademark of Whirlpool S/A. All rights reserved.



CONTACT

If after these instructions you still have doubts, please do not hesitate to contact our Technical Support.
www.embraco.com